

## USER MANUAL OPERATION AND MAINTENANCE

Dear User,

**Neometrix is grateful for this opportunity provided to us to offer our products & services to you. We sincerely hope that you will be delighted to use our system and give us more opportunities to serve you.**

Neometrix is very focused on Aviation and Railway industries and offers complete range of systems & services which can be of immense use to you. We specialize in Hydraulic/ Servo Hydraulic Test Rigs, Fuel System Test Rigs, Pneumatic System Test Rigs, Oxygen/ Special Gases system Test Rigs, Very High Pressure Systems, Electronic & Electrical Test Rigs. Our services include among others, the followings:

- State of the art Test Rig Design, Development, Fabrication, Installation, Commissioning, Training & Support.
- Refurbishment/ Up gradation of the Existing Test Rigs.
- Maintenance (AMC) contracts of Existing Test Rigs.
- Operations Contract for the Test Rigs.
- Setting up of complete Testing Infrastructure including civil infrastructure.

The following pages talk about some of our systems in brief. Please feel free to contact us for details of any particular system of your interest.

Neometrix is committed to offer its best solutions & services to you all the times and **wish to become your preferred supplier for these services.**

With Best Regards,

**Shailendra Pratap Singh**  
**CEO**

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 1 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

## Warnings:

1. Make sure that all electronic products are earth-grounded, to ensure Personal safety and proper operation.



2. All sensors are very sensitive; please never try to touch them.

## Table of Contents

Sr. No.	Description	Page No
1	Neometrix Engineering Introduction	5-7
2	Introduction of the System	8-9
3	System Specifications	10
4	Do's & Don'ts for the System	11-12

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 2 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023
--------------	--	--------------------------

5	Starting of the System	13-14
6	Working of the System	14-15
7	Automatic Mode Working	16-18
8	Manual Mode Working	19-20
9	Maintenance	21-22

## 1. Neometrix Engineering Introduction:

Neometrix Engineering Pvt. Ltd. is a complete engineering solutions company based in New Delhi/ Noida.

**We specialize in CUSTOM BUILT Turnkey Engineering Solutions.**

**We have expertise in various engineering domains** like Hydraulics, Servo Hydraulics, ATF (Fuel), Mechanical, Pneumatic, Oxygen/ Helium (High Purity Gases), Electronics/ Electrical Test Benches, and Complete PC Based Automation Solutions.

We have experts in Mechanical Engineering, Chemical Engineering, Electrical/ Instrumentation Engineering, Software, Civil Engineering, Aeronautical engineering and other engineering fields.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 3 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

# NEOMETRIX

Complete Engineering Solutions Company

An ISO 9001 2008 Company

The company has a team of ~30 highly qualified engineers and has an experience of more than 75 successfully delivered projects. We are very closely working with **HAL, RDSO, Railways, Defense Establishments, Labs and Private Industries.**

The founders are graduates from IIT Kanpur and the company remains very closely linked with IITs. We utilize the expertise available there as and when required.

We have an exclusive relationship with Parker USA ([www.parker.com](http://www.parker.com)) for supplying Hydraulic Systems to HAL. Parker is world leader in Hydraulics (Fluid Motion & Control).

We have an exclusive relationship with Haskel USA ([www.haskel.com](http://www.haskel.com)) for supplying very high pressure systems. Haskel is world leader in very High Pressure products.

We are alliance partners of **National Instruments USA** ([www.ni.com](http://www.ni.com)), world leader in PC Based Test Measurement and Automation.

**With such alliances and our own engineering capabilities, we are in a position to deliver you state of the art world class Test Rig.**

**Neometrix is a member (as Industry Partner with ministry of HRD & Ministry of Railways) of TMRS (TECHNOLOGY MISSION FOR**

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 4 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

Neometrix Engineering (P) Limited. E-148,Sec-63 Noida-201301.

Tel: +91-120-4500800, Fax: +91-120-4500888, contact@neometrix.in

**RAILWAY SAFETY) and we are working on several Railway Safety projects with IIT Kanpur & RDSO.**

**Neometrix values its association with RDSO and wishes to become its most preferred partner for such services.**

We are working very closely with Research Designs & Standards Organization (RDSO).

## **2. Introduction of the System:**

The system is designed to test the performance/Functional testing of the following 18 types of pneumatic valves of IRAB Brake system for for electric locomotives.

The system is consisting Brake Pipe, Auxiliary Reservoir, Brake Cylinder Reservoir and Control Reservoir.

The test stand have a structure composed of SS –Section with pressure gauges construction housing with digital pressure gauges at front of the stand.

The right and left side and the rear side of the test stand is provided with detachable covers and doors. All the air reservoirs and pneumatic piping are accommodated inside of the test stand.

The test stand operation is controlled by the computer system by means of predefined software.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 5 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

## TEST RIG FOR IRAB BRAKE SYSTEM Test the following Valves one by one:

1	A9 Automatic brake valves	7	N-1 Reducing Valve	13	Air Flow Measuring Valve
2	A9 Automatic brake valves	8	Feed Valve C2N/FT1/Combined Feed Valve	14	R-6 Relay Valve
3	C2W Relay Valve	9	C2W Distributor Valve	15	J-1 Safety Valve
4	C2W Relay Valve-6mm Chock	10	Duplex Check Valve	16	Emergency Brake Application Valve
5	MU-2B Valve	11	GM Type Drain Valve	17	Pressure Switch
6	F-1 Selector Valve	12	24-A Double Check Valve	18	Magnet Valve

The system works on a predefined Test Sequence with an option to test the particular test.

### 3. System Major Specifications

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 6 of 20	Document Name: A3111-PED-OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

Medium	=	Compressed Air
Pressure Rating	=	10.5 Kg/cm <sup>2</sup>
Air supply Pressure Range	=	8-10 Kg/cm <sup>2</sup>
Flow Rate	=	70CFM (2000 LPM)
Temperature Range	=	Ambient up to 48°C
Power Supply	=	230V + 10% -10% Single Phase 50 HZ

## Contents:

### THE TEST RIG FOR IRAB BRAKE SYSTEM FOR ELECTRIC LOCOMOTIVES CONSIST OF:

- **Test Bench stand including Air reservoirs and pneumatic piping**
- **Measuring System (DAQ Panel)**
- **Computer**
- **Printer**
- **UPS**
- **Control Panel**
- **PLC Panel**
- **Air Dryer**

## 4. Do's & Don'ts for the System

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 7 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

## Do's:

1. Read the User Manual fully before operating the System.
2. Read the Pneumatic Circuit and understand which Valve/ Component on Panel do what.
3. Check the proper closing of the Supply Valve of the system when it is not in operation.
4. Check the Source Pressure before operation.

## Don't:

1. Never touch the sensors or their mountings.
2. Touch any circuitry inside the panel.
3. "ON" the MCB before starting the computer.

## 5. Starting Of The System:


- Give the DAQ panel UPS to Power Supply 230V +10% - 10% Single Phase, 50 Hz.
- Turn ON the Computer CPU and Monitor
- Turn on the PLC panel on/off switch at "ON" Position.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 8 of 20


Document Name: A3111-PED-  
OPERATIONAL AND  
MAINTENANCE MANUAL-IRAB  
BREAK REV-00 - Copy

4<sup>th</sup> MAR,2023



- Turn “ON” the Main switch of control panel at DAQ panel.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 9 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



- Connect the compressed air inlet line to the air dryer inlet line and open the inlet ball valve of air dryer and test bench.
- Give Power Supply 230V, Single Phase, 50 Hz. To the Air dryer

## 6. Working Of The System:

The System is consisting dual working mode i.e. Automatic and manual

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 10 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023

In Automatic mode the Test will be perform according to the predefined sequence automatically and also with an option for a particular test according to the requirement.

In manual mode the test will be done with control Panel and Toggles Switch.

**Mode Selection-** The mode selection can be done with the Mode Selector with an option-

- 1- Automatic Mode.
- 2- Manual Mode.


**Automatic Mode-**This mode can be selected from the Control Panel Selector Switch.

To start the testing follow following steps:

Switch on the computer and open the CCUBTB test Run File from the Desktop the Main Menu Window will appear as show below:

Click here once  



The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 11 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



Note: For first time Run file opening clicking on top left play button as indicated on above screen to run the software.


**PARAMETER-** To insert the test parameter(if required) click on PARAMETER icon as per below

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 12 of 20	Document Name: A3111-PED-OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



After clicking the **PARAMETER** icon the **CCUBTB** detail window will appear as shown-

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 13 of 20	Document Name: A3111-PED-OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



**Click on Particular Valve for Parameter setting if applicable**

**START TEST: Click on TEST SELECTION from main Menu**

**After clicking the TEST SELECTION icon the CCUBTB detail window will appear as shown-**

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 14 of 20	Document Name: A3111-PED-OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



To start a test click on a particular valve as per test setup ready for testing. Now Test can be started by clicking on START button, Test will automatically run for define time and report will be save in PDF format.

To start the other valve testing follows the same procedure from Test Selection Screen after Test setup.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 15 of 20

Document Name: A3111-PED-  
OPERATIONAL AND  
MAINTENANCE MANUAL-IRAB  
BREAK REV-00 - Copy

4<sup>th</sup> MAR,2023



**Manual Mode**-This mode can be selected from the Control Panel Selector Switch. All the operation of valve control will be done by toggle switch as per test requirement of testing units.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 16 of 20

Document Name: A3111-PED-  
OPERATIONAL AND  
MAINTENANCE MANUAL-IRAB  
BREAK REV-00 - Copy


4<sup>th</sup> MAR,2023



## 7. Maintenance of the Test Stand

From the Main menu Click on the MAINTENANCE icon, after clicking on maintenance icon following windows will appear

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.		
Page 17 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023



On above screen select the selector switch on maintenance mode.  
After this particular valve proper functioning can be monitored by switching on from the screen.

### ❖ Weekly Maintenance

- Closed the air dryer inlet and outlet valve.
- Closed the air compressor outlet valve
- Exhaust the air from main reservoir by opening the drain valve of reservoir from inside the test stand panel.
- Now check the seals for fittings if any leakage observed during testing and tight it properly.
- Check the air dryer function as per air dryer maintenance manual.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 18 of 20

Document Name: A3111-PED-  
OPERATIONAL AND  
MAINTENANCE MANUAL-IRAB  
BREAK REV-00 - Copy

4<sup>th</sup> MAR,2023

- Check the Air filter drainage and drain the moisture.
- ❖ **Monthly Maintenance**
  - Check the pressure gauge calibration certificate if the calibration of pressure gauges and pressure transmitter is over dated then remove and do the needful for calibration.
  - After calibration of pressure gauges and pressure transmitter mount on its place as per circuit.
  - Now closed the main reservoir drain valve
  - Open the air dryer inlet valve and outlet valve and supply on compressor air supply line
  - Now observed if any leakage on circuit
  - If not then click on auto mode from maintenance screen.
  - Now select on TEST SCREEN icon and do the testing of unit as per requirement.

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 19 of 20

Document Name: A3111-PED-  
OPERATIONAL AND  
MAINTENANCE MANUAL-IRAB  
BREAK REV-00 - Copy

4<sup>th</sup> MAR,2023

END OF DOCUMENT

# THANK YOU

The information contained herein is confidential and proprietary to Neometrix Engineering (P) Ltd and the same can not be reproduced or disclosed in whole or in part. The information is not to be used for the design or manufacture of any related equipment or processes without written approval from Neometrix Engineering (P) Ltd.

Page 20 of 20	Document Name: A3111-PED- OPERATIONAL AND MAINTENANCE MANUAL-IRAB BREAK REV-00 - Copy	4 <sup>th</sup> MAR,2023
---------------	--	--------------------------